



E6WH - 6" DEEP 45 DEGREE WIND DRIVEN RAIN BLADE EXTRUDED ALUMINUM STATIONARY LOUVER



SECTION VIEW



ELEVATION VIEW

BLADE - 0.081" THICKNESS TYPE 6063-T5 EXTRUDED ALUMINUM
 FRAME - 0.081" THICKNESS TYPE 6063-T5 EXTRUDED ALUMINUM
 DESIGNED FOR 30 PSF WIND LOAD
 SIZES 12" WIDE X 12" HIGH UP TO UNLIMITED SIZE AVAILABLE

- OPTIONS:
- MOUNTING FOR VARIOUS OPENING TYPES (SEE FRAME STYLES BELOW)
 - ARCHITECTURAL SHAPES (SEE SPECIAL SHAPES TECH SHEET)
 - HIGHER WIND LOAD RATINGS
 - ARCHITECTURAL FINISHES
 - VARIOUS SCREENS

* SEE MOUNTING OPTIONS TECHNICAL SHEET FOR MORE FRAME STYLES:

1. J-CHANNEL FOR SIDING OR STUCCO
2. G-CHANNEL FOR GLAZING INTO STOREFRONT OR CURTAINWALL

CONSTRUCTION	FRAME STYLE *	BLADE STIFFENER	VERTICAL MULLION (MULTIPLE PANELS WIDE)	HORIZONTAL MULLION (MULTIPLE PANELS HIGH)
STANDARD	<p>EXTERIOR</p> <p>CHANNEL "C" FRAME</p>	<p>EXTERIOR</p> <p>BLADE SUPPORT BRACKETS</p> <p>STIFFENER (EVERY 60" WIDTH MAX)</p> <p>VERTICAL</p>	<p>EXTERIOR</p> <p>MULLION COVER ENTIRE HEIGHT</p> <p>EXPOSED</p>	<p>EXTERIOR</p> <p>EXPOSED</p>
OPTIONAL	<p>EXTERIOR</p> <p>1.50"</p> <p>JAMB</p> <p>FLANGE "F" FRAME</p>	<p>HORIZONTAL</p> <p>HORIZONTAL STIFFENER EVERY 48" MAX HEIGHT</p> <p>HORIZONTAL (VDR BLADES)</p>	<p>EXTERIOR</p> <p>BLADE SUPPORT BRACKETS</p> <p>STIFFENERS (JOINED BY INSTALLER)</p> <p>HIDDEN</p>	<p>EXTERIOR</p> <p>STIFFENERS (JOINED BY INSTALLER)</p> <p>HIDDEN</p>

ARCHITECTURAL L · O · U · V · E · R · S

266 W Mitchell Ave - Cincinnati, OH 45232
 PH: (888) 568-8371 Fax: (888) 568-8370

PROJECT			
CONTRACTOR			
ARCHITECT			
DRAWN BY: JRR	DATE: 07/2014	DRAWING TYPE: TECHNICAL SHEET	DRAWING TITLE: E6WH

MODEL: E6WH



Louver Performance Data



The Architectural Louvers Model E6WH is tested in accordance with AMCA 500-L Laboratory Methods of Testing Air Louvers for Rating. The data presented are the results of these tests. Tested louver size is 48" wide x 48" high (unless noted otherwise) and does not include the effects of bird screen.

Airflow Resistance

(Std Air Density - .075 lb/ft³) - Test Figure 5.5-6.5



Architectural Louvers certifies that model E6WH louver shown herein is licensed to bear the AMCA seal. The ratings shown are based on tests and procedures performed in accordance with AMCA Publication 511 and comply with the requirements of the AMCA Certified Ratings Program. The AMCA Certified Ratings Seal applies to air performance ratings and wind driven rain ratings only.

Model: E6WH resistance to airflow
Free area velocities (shown left) are higher than average core, face or duct velocity. See louver application information.

Wind Driven Rain Test per AMCA Standard 500-L-99, Figure 5.11 Setup Performance.
Test Louver Size 40.87" W x 40.87" H (1m x 1m Core Size).

	Wind Velocity (mph)	Rain Fall Rate (in. / hour)	Core Velocity (fpm)	Airflow (cfm)	Louver Free Area Velocity (fpm)	Water Penetration Effectiveness (Percentage)	Water Penetration Classification Rating
29 MPH Wind Velocity and 3" Rainfall Rate	29	3	0	0	0	100.0	A
	29	3	132	1417	249	100.0	A
	29	3	197	2117	372	100.0	A
	29	3	287	3092	544	100.0	A
	29	3	380	4092	720	100.0	A
	29	3	472	5083	894	100.0	A
	29	3	587	6317	1111	99.9	A
	29	3	680	7323	1288	99.9	A
	29	3	780	8397	1477	99.9	A
	29	3	865	9309	1637	97.8	B
	29	3	991	10666	1876	82.1	C
	50 MPH Wind Velocity and 8" Rainfall Rate	50	8	0	0	0	100.0
50		8	96	1028	181	100.0	A
50		8	194	2093	368	100.0	A
50		8	284	3055	537	100.0	A
50		8	400	4312	758	100.0	A
50		8	496	5341	939	100.0	A
50		8	571	6145	1081	100.0	A
50		8	679	7311	1286	99.8	A
50		8	786	8459	1488	98.6	B
50		8	878	9452	1662	91.2	C
50		8	974	10482	1843	70.3	D

The discharge loss coefficient class for louver E6WH is 3. The higher the coefficient, the lower the resistance to airflow.

Class	1	2	3	4
Discharge Loss Coefficient	.4 and Above	.3 to .399	.2 to .299	.199 and below



Application of any louver involves selecting an airflow velocity through the louver free area (free area velocity in fpm) that produces an acceptable pressure drop and for intake applications and minimizes carry-over of normally occurring rain. Architectural Louvers does not warrant our louvers to prevent water penetration under all combinations of wind and rain. 99% water resistance effectiveness during testing through Model E6WH ends at 1286 fpm free area velocity. Louver selection using a free area velocity below 1286 fpm is recommended. Louver selection involves the following steps, and depending on the information provided, either step may come first.

Select Free Area Velocity - Fan Forced Intake:

Using the Airflow Resistance Chart, select a free area velocity that produces an acceptable pressure drop with minimal water penetration. (Water penetration may not need to be considered when selecting exhaust louvers.)

Determine Louver Free Area:

Using the free area velocity from previous step and total cfm, determine the louver Free Area required. Using louver Free Area Chart, select a louver with the required free area. If louver size is given, determine free area from chart and work backwards to determine maximum airflow. See examples below.

Free Area Chart (ft²)

		Louver Width (Inches)							
		12	24	36	48	60	72	84	96
Louver Height (Inches)	12	0.25	0.56	0.88	1.19	1.50	1.75	2.05	2.35
	24	0.75	1.67	2.60	3.52	4.44	5.31	6.22	7.13
	36	1.25	2.78	4.32	5.85	7.39	8.87	10.39	11.92
	48	1.74	3.89	6.04	8.19	10.34	12.42	14.56	16.70
	60	2.24	5.00	7.76	10.52	13.28	15.98	18.73	21.48
	72	2.74	6.11	9.48	12.86	16.23	19.54	22.90	26.26
	84	3.24	7.22	11.20	15.19	19.17	23.10	27.07	31.05
	96	3.73	8.33	12.93	17.52	22.12	26.66	31.24	35.83

Louver Selection Examples - Fan Forced Intake:

Example 1:

Airflow given as 6000 cfm – select louver size.

- A. Determine louver free area by dividing airflow by free area velocity (do not exceed 1286 fpm on intake louver applications).

$$\begin{aligned} \text{cfm} / \text{fpm} &= \text{ft}^2 \\ 6000 / 1286 &= 4.67 \end{aligned}$$

- B. Select a louver with at least the required louver free area from Free Area Chart above.

Width	x	Height	Free Area from Chart
36	x	48	6.04

(Other selections available – See Free Area Chart above)

- C. Calculate Free Area Velocity

$$\begin{aligned} \text{fpm} &= \text{cfm} / \text{ft}^2 \text{ free area of louver} \\ 993 &= 6000 / 6.04 \end{aligned}$$

- D. Check the pressure drop of the selected louver at the calculated airflow (Airflow Resistance Chart on Page 2).

in w.g. = 0.363 at 993 fpm free area velocity

Example 2:

Louver size given as 96 W x 48 H – determine maximum airflow.

- A. Use Free Area Chart to obtain ft² for given size

Free Area = 16.7 sq ft

- B. Multiply Free Area x Free Area Velocity (Do not exceed 1286 fpm on intake louver applications).

$$\begin{aligned} \text{ft}^2 \times \text{fpm} &= \text{cfm} \\ 16.7 \times 1286 &= 21474 \end{aligned}$$

- C. Check the pressure drop of the selected louver at the calculated airflow (Airflow Resistance Chart on Page 2).

in w.g. = 0.608 at 1286 fpm free area velocity